



**NOTES:**

1. FOAM MUST BE CUT OUT IF NECESSARY TO PRESERVE EXISTING DRAIN SIZE.
2. TEMPORARILY COVER DRAIN TO PERFORM FOAM APPLICATION TO ENSURE NO DEBRIS ACCUMULATES IN DRAIN PIPE.
3. SHAPE (GRIND) FOAM AROUND THE BOWL TO MAKE STRAINER FLAT AND IN CONTACT WITH ROOF TO PREVENT PASSAGE OF DEBRIS INTO DRAIN.
4. SLOPE FOAM TO DRAIN TO PREVENT PONDING OF WATER AROUND DRAIN.

Roof\_Drain[1]



**Bayer MaterialScience LLC**  
 Spray Insulation & Roofing Materials  
 Polyurethanes

2400 Spring Stuebner Road West  
 Spring, TX 77389

Phone: 281 350-9000  
 Fax: A: 281 288-6450  
 B: 281 288-3348  
 Other: 800 221-3626

[www.baysystemsspray.com](http://www.baysystemsspray.com)