

Note:
Wall cavity should be filled with spray foam insulation for maximum sound attenuation.

